

Manual, Assembly instruction: Brodit 852756

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 1 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Press the grooved part of the ProClip into the gap at pos. 1 between the center console and the frame surrounding the control panel.