

Manual, Assembly instruction: Brodit 852760

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Open the glove compartment. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Hook the upper part of the ProClip over the the edge between the air vents at pos. 1.

3. Press forward on the ProClip so the lower part hooks over the edge of the glove compartment at pos. 2. Close the glove compartment.