

Manual, Assembly instruction: Brodit 852762

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at pos. 1 to widen the gap between the dashboard and the frame surrounding the control panel. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Press the left part of the ProClip into the gap below the gap opener at pos. 1. Pull out the gap opener.

3. Press the gap opener into the gap at pos. 2 between the upper and the lower part of the dashboard. Press forward on the ProClip so the right part hooks into the gap above the gap opener at pos. 2. Pull out the gap opener.