

## Manual, Assembly instruction: Brodit 852771

Center mount

1.)



2.)



3.)



4.)



**Attention: This ProClip fits all dashboard versions of the Ford Taurus and Mercury Sable 2000- . If your stereo LCD display is a little different designed than the one shown in the pictures, dont worry: this will NOT affect the attaching procedure & placement of the ProClip. Just follow the instructions below.**

1. Press the enclosed gap opener into the gap between the stereo and the surrounding panel frame to widen the gap.
2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener and at the same time: flip the ProClip upwards and forward towards the vent, so the angled edge on the lower part of the ProClip hooks behind the stereo panel. Pull out the gap opener
3. Press forward on the upper part of the ProClip so the grooved edge snaps into the gap between the padded dashboard and the air vent panel frame. Press until you see or hear/feel it snaps into place.
4. The ProClip in place.