

Manual, Assembly instruction: Brodit 852777

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Place the upper part of the ProClip over the gap between the padded dashboard and the frame surrounding the air vents.
2. Press forward on the upper part of the ProClip so the grooved edge snaps into the gap. Press until you see or hear/feel it snaps into place.
3. Press forward on the lower part of the ProClip until it snaps into the gap between the padded part of the dashboard and the air vent frame.
4. The ProClip is in place.