

Manual, Assembly instruction: Brodit 852779

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Clean the surface with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.

1. Place the ProClip over the gap between the control panel and the dashboard.
2. Press the ProClip into the gap.
3. Press forward on the ProClip until you hear or see/feel it snaps into place.
4. The ProClip in place.