

Manual, Assembly instruction: Brodit 852786

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Peel off the cover of the adhesive tape on the ProClip fixing piece.

1. Press the fixing piece into the gap between the control panel and the dashboard. Press on the top of the piece, away from the steering wheel, so the adhesive tape attaches.
2. Peel off the cover of the adhesive tape on the ProClip face plate. Place the face plate over the fixing piece so the holes match.
3. Fasten the face plate on the fixing piece by using the enclosed screws.
4. ProClip in place.