

Manual, Assembly instruction: Brodit 852788

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip attaching piece.

1. Press the attaching piece into the gap above the gap opener.
2. Slide the attaching piece upwards in the gap. Press away from the steering wheel so the adhesive tape attaches. Pull out the gap opener.
3. Peel off the cover of the adhesive tape on the ProClip faceplate. Place the faceplate over the attaching piece so the holes match. Screw the faceplate onto the attaching piece by using the enclosed screws.
4. ProClip in place.