

Manual, Assembly instruction: Brodit 852789

Angled mount



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at to widen the gap between the dashboard and the frame surrounding the control panel. Peel off both adhesive tape covers on the ProClip.
2. Press the right part of the ProClip into the gap below the gap opener.
3. Press forward/towards the steering wheel so the left part snaps into the gap between the control panel and the surrounding frame. Pull out the gap opener.
4. ProClip in place.