

Manual, Assembly instruction: Brodit 852793

Angled mount

1.)



2.)



3.)



4.)



Attention: Read all instructions before attaching the ProClip. Clean the surface with the enclosed alcohol pad. This ProClip consists of two parts. Part 1: Attaching piece Part 2: ProClip faceplate

1. Peel off the cover of the adhesive tape on Part 1 and press the angled edge of Part 1. into the gap between the panel frame surrounding the stereo and the padded console edge.

2. Push forward on the left side of Part 1. towards the padded console edge, so the angled edge of Part 1. hooks under/behind the panel frame and the adhesive sticks to the padded console edge.

3. Peel off the cover of the adhesive tape on Part 2. Adjust Part 2 so the holes match over the holes in Part 1. Use the enclosed screws to screw Part 2 onto Part 1.

4. The ProClip in place.