

Manual, Assembly instruction: Brodit 852798

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame. Peel off the cover of the adhesive tape on the ProClip fixing piece.

1. Press the fixing piece into the gap above the gap opener.

2. Press forward on the fixing piece until you hear or feel/see it snaps into place into the gap. Pull out the gap opener.

3. Press e.i. a screwdriver through the predrilled holes in the ProClip face plate. Peel off the cover of the adhesive tape on the face plate. Place the face plate over the fixing piece so the holes match. Screw the face plate onto the fixing piece by using the enclosed screws.

4. The ProClip in place.