

Manual, Assembly instruction: Brodit 852803

Center mount



Attention! Read all instructions before attaching the ProClip. This ProClip can also be placed on the over the passengers side air vent.

1. Press the thin end of the enclosed gap opener into the gap to widen the gap between the dashboard and the frame surrounding the air vents. Peel off the cover of the adhesive tape on the ProClip.

2. Press the lower part of the ProClip, with adhesive tape, into the gap between the control panel and the frame surrounding the air vents.

3. Press the upper part of the ProClip, with angle, into the gap next to the gap opener. Pull out the gap opener.

4. ProClip in place.