

Manual, Assembly instruction: Brodit 852805

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the padded dashboard and the climate control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Press the vertical edge on the ProClip into the gap above the gap opener. (start by inserting the lower corner of the mount). Pull out the gap opener.

3. Press firmly forward on the upper left side of the ProClip so the angled edge goes into the gap between the panel frame surrounding the stereo and the air vent. Press until you see or hear/feel the angled edge snaps over the panel frame edge. Press forward on the upper right side of the ProClip to make sure the angled edge has snapped properly over the panel frame edge.

4. The ProClip is in place.