

## Manual, Assembly instruction: Brodit 852806

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.** This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate.

**1.** Place the grooved edge of Part 1 towards the gap between the climate control panel and the padded console edge.

**2.** Press Part 1 firmly towards the padded console wall with your left hand and at the same time: press firmly forward on Part 1, towards the climate control panel, so the grooved edge goes into the gap between the climate control panel and the padded console edge. Press until you see or hear/feel it snaps into place. (Note: the gap is very tight so you may have to start pressing on top of Part 1 and then follow through with the lower part of Part 1.)

**3.** Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side attaching to the climate control panel. Screw Part 2 onto Part 1 using the enclosed screws.

**4.** The ProClip is in place.