

Manual, Assembly instruction: Brodit 852808

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap openers into the gap between the center console panel and the console edge, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Place Part 1 in the same position as in the picture, in the same height. Place the angled edge of Part 1 in the gap between the center console panel frame and the console edge.

2. Press the angled edge firmly into the gap and at the same time: bend Part 1 to the left so the angled edge hooks behind the console edge panel and the adhesive tape attaches to the center console panel.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the right side attaching to the console edge. Screw Part 2 onto Part 1 using the enclosed screws.

4. The ProClip is in place.