

Manual, Assembly instruction: Brodit 852809

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Peel off the cover of the adhesive tape on the ProClip.

1. Press the right part of the ProClip, with groove, into the gap between the air vent and the surrounding panel.
2. Press on the right part of the ProClip until you hear or see/feel it snaps into place.
3. Press the left part of the ProClip, with adhesive tape, into the gap between the stereo and the surrounding panel.
4. The ProClip in place.