

Manual, Assembly instruction: Brodit 852816

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Peel off the cover of the adhesive tape on the ProClip.

1. Press the lower part of the ProClip, with adhesive tape, into the gap between the console and the frame surrounding the control panel.
2. Hook the upper part of the ProClip, with groove, into the gap between the control panel and the surrounding frame.
3. Press forward on the ProClip.
4. The ProClip in place.