

Manual, Assembly instruction: Brodit 852819

Angled mount



Attention! Read all instructions before attaching the ProClip Part 1: The attaching part (the smallest part)
Part 2: The ProClip faceplate

1. Press the thin end of the enclosed gap openers into the gap between the climate control panel frame and the padded dashboard to widen the gap. Peel off the cover of the adhesive tape on Part 1.

2. Press the angled thin end of Part 1 into the gap between the gap openers. Press it firmly/hard forward at the same time you bend it to the right.

3. Press Part 1 all the way in until the adhesive attaches. Pull out the gap openers.

4. Press a Phillips screwdriver firmly through the large holes in Part 2 to open them up. Peel off the cover of the adhesive tape. Place Part 2 onto Part 1 so the holes match and the adhesive tape is on the left. Screw the enclosed screws into the holes. ProClip in place.