

Manual, Assembly instruction: Brodit 852824

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Press the thin end of one of the enclosed gap openers into the gap between the frame surrounding the control panel and the air vent frame to widen the gap. Peel off both adhesive tape covers on the ProClip.

1. Press the lower curved part of the ProClip into the gap next to the gap opener. Press firmly until it snaps into the gap. Pull out the gap opener.

2. Press the thin end of both the gap openers into the gap between the padded dashboard and the air vent frame (on each side of the ProClip) to widen the gap.

3. At the same time: Press forward on the upper part of the ProClip and downwards on top of the ProClip so the angled edge snaps into the gap between the gap openers. Pull out the gap opener.

4. The ProClip in place.