

Manual, Assembly instruction: Brodit 852826

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Press the thin end of the enclosed gap opener into the gap to widen the gap between the frame surrounding the control panel and the frame surrounding the air vents.

1. Press the lower part of the ProClip, with groove, into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap between the dashboard and the frame surrounding the air vents. Hook the upper part of the ProClip, with angle, into the gap next to the gap opener.
3. Press downwards on the top of the ProClip so it goes into the gap. Pull out the gap opener.
4. The ProClip in place.