

Manual, Assembly instruction: Brodit 852828

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip fixing part.

1. Press the fixing part into the gap between the dashboard and the frame surrounding the control panel.
2. Press on the fixing part, away from the steering wheel, so the adhesive tape attaches to the dashboard.
3. Press e.i. a screwdriver through the predrilled holes in the ProClip face plate. Peel off the cover of the adhesive tape on the face plate. Place the holes in the face plate over the holes in the fixing piece so they match. Screw the face plate onto the fixing piece by using the enclosed screws.
4. The ProClip in place.