

Manual, Assembly instruction: Brodit 852830

Center mount NOT for wood grain panel/kevlar look.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap in the control panel. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press forward on the ProClip so it goes properly into place.
4. The ProClip is in place.