

Manual, Assembly instruction: Brodit 852832

Angled mount ONLY for Base model.



Attention! Read all instructions before attaching the ProClip

1. Remove the screw at pos. x.
2. Press the grooved part of the ProClip into the gap at pos. 1 between the upper and the lower part of the control panel. Press forward on the ProClip until you see or hear/feel it snap into place.
3. Screw the enclosed screw into place at pos. x.