

## Manual, Assembly instruction: Brodit 852833

Angled mount ONLY for Base model.



**Attention! Read all instructions before attaching the ProClip**

1. Remove the screw at pos. x.
2. Press the grooved part of the ProClip into the gap at pos. 1 between the upper and the lower part of the control panel. Press forward on the ProClip until you see or hear/feel it snap into place.
3. Screw the enclosed screw onto pos. x.