

Manual, Assembly instruction: Brodit 852834

Angled mount



Attention: Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1: Attaching piece Part 2: ProClip faceplate

1. Peel off the cover of the adhesive tape on Part 1. Press Part 1 into the gap between the stereo and the surrounding control panel.

2. Part 1 is in place.

3. Press a screw driver through the holes in the faceplate on Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1. so the holes match up and the adhesive tape on Part 2 is on the left side. Screw the enclosed screws into the holes in Part 2. **4.** The ProClip is in place.