

Manual, Assembly instruction: Brodit 852838

Angled mount NOT for models with navigation screen.

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching piece. Part 2. ProClip faceplate. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame in the same position as in the picture.

1. Press the angled edge of Part 1 into the gap below the gap opener.

2. Push Part 1 away from the steering wheel so the angled edge hooks under/behind the control panel. Pull out the gap opener.

3. Press a screwdriver through the holes in the faceplate on Part 2 to open them up. Peel off both adhesive tape covers on Part 2. Place Part 2 onto Part 1 so the holes match up. Screw the enclosed screws into the holes.

4. The ProClip is in place.