

Manual, Assembly instruction: Brodit 852841

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching piece. Part 2. ProClip face plate. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the center panel. Peel off the cover of the adhesive tape on Part 1.

1. Press the angled left edge on Part 1 into the gap above the gap opener.
2. Push Part 1 away from the steering wheel, so the angled edge hooks under/behind the console frame and the adhesive tape sticks to the dashboard.
3. Press a screwdriver through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 over Part 1 so the holes match up. Screw the enclosed screws into the holes on Part 2.
4. The ProClip is in place.