

Manual, Assembly instruction: Brodit 852849

Center mount



Peel off both adhesive tape covers on the ProClip.

1. Press forward on the panel surrounding the display.

2. Press the lower part of the ProClip, with curve, into the gap between the panel surrounding the display and the surrounding panel.

3. Press the upper part of the ProClip, with angle, into the gap between the frame surrounding the air vent and the frame surrounding the panel

4. The ProClip is in place.