

Manual, Assembly instruction: Brodit 852854

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the lower part of the ProClip into the gap between the center console and the dashboard.
2. Press the enclosed gap opener into the gap between the stereo/navigation equipment and the dashboard.
3. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.