

Manual, Assembly instruction: Brodit 852855

Center mount ONLY for models with info display.



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip.

1. Press the upper part of the ProClip, with curve, into the gap between the clock and the surrounding panel.
2. Press the enclosed gap opener into the gap between the panel surrounding the air vents and the control panel to widen the gap.
3. Press the lower part of the ProClip, with groove, into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.