

Manual, Assembly instruction: Brodit 852856

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Loosen the screw at the upper left corner by the glove compartment. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard. Slide the ProClip upward, as far as possible. Flip the ProClip leftward so the angled right edge hooks into the gap and the left end hooks over the edge of the dashboard. Press the angled edge on the left part of the ProClip into the gap below the gap opener.
3. Pull out the gap opener. Tighten the screw. Close the glove compartment.
4. The ProClip is in place.