

Manual, Assembly instruction: Brodit 852857

Angled mount



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching piece. Part 2. ProClip face plate. 1 and 2. Peel off the cover of the adhesive tape on Part 1. Press Part 1 into the gap between the control panel and the dashboard. Press on Part 1, away from the steering wheel, so the edge hooks under/behind the panel.

3. Press a Philips screwdriver through the predrilled holes in part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 on Part 1 so the holes match up. Screw Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.