

Manual, Assembly instruction: Brodit 852859

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Peel off all adhesive tape covers on the ProClip.

1. Press the long part of the ProClip into the gap on top of the dashboard.
2. Pull the ProClip towards you and press it downwards.
3. Hook the short part of the ProClip into the gap between the dashboard and the frame surrounding the instrument display.
4. The ProClip is in place.