

Manual, Assembly instruction: Brodit 852861

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the upper part of the ProClip, with angle, into the gap between the dashboard and the frame surrounding the air vents.

2. Press the lower part of the ProClip, with groove, into the gap between the control panel and the dashboard. If any of the gaps is too tight, press the thin end of the enclosed gap opener into the gap to widen the gap.