

Manual, Assembly instruction: Brodit 852865

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.
2. Hook the angled edge on the upper part of the ProClip into the gap between the panel surrounding the air vents and the dashboard.
3. Press downward on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.