

Manual, Assembly instruction: Brodit 852867

Angled mount



Attention! Read all instructions before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching piece. Part 2. ProClip face plate. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on Part 1.

1. Press Part 1 into the gap above the gap opener.

2. Press on Part 1, away from the steering wheel, so the angled edge hooks under/behind the control panel.

3. Press a Philips screwdriver through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 over Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.