

Manual, Assembly instruction: Brodit 852870

Center mount

1.)



2.)



3.)



4.)



Attention: Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the padded dashboard to widen the gap.

2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener. Slide the ProClip sideways (left or right) to desired position.

3. Press forward on the lower part of the ProClip so it goes into the big gap between the dashboard and the center dash ledge. At the same time, press upwards on the lower part of the ProClip so the grooved edge snaps over the panel edge of the center dash ledge. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.