

Manual, Assembly instruction: Brodit 852871

Angled mount

1.)



2.)



3.)



4.)



Attention: Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip and place it over the center dash console edge.
Note: avoid making the adhesive tape attach yet - it will automatically attach during the rest of the installation procedure.

2. Press the left side of the ProClip towards the padded console edge and at the same time, press forward on the ProClip so the grooved edge goes into the gap between the console edge and the stereo. Press until you see or hear/feel it snap into place.

3. Press forward on the right side of the ProClip so the angled edge goes into the gap between the center console edge and the center console sidewall. Press until you see or hear/feel it snap into place.

4. The ProClip is in place.