

Manual, Assembly instruction: Brodit 852879

Center mount



Attention! Read all instructions before attaching the ProClip.

1. Peel off both adhesive tape covers on the ProClip. Press the right part of the ProClip into the gap between the navigation system and the surrounding frame.
2. Press the long left part of the ProClip into the gap between the control panel and the dashboard.
3. Press on the ProClip so the adhesive tapes stick.
4. The ProClip is in place.