

Manual, Assembly instruction: Brodit 852885

Center mount WRX: NOT for Limited WRX Hatchback models.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel section below the air vent and the panel frame surrounding the stereo, to widen it. Peel off the cover of adhesive tape on the ProClip.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the dashboard and the air vent panel frame. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.