

Manual, Assembly instruction: Brodit 852886

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Place the ProClip so the upper part is aligned with the lower part of the stereo. Open the glove compartment.

2. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard. Peel off both adhesive tape covers on the ProClip. Press the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Press forward on the ProClip so the angled edge of the right part snaps into the gap between the glove compartment and the dashboard. Close the glove compartment.

4. The ProClip is in place.