

Manual, Assembly instruction: Brodit 852891

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the padded dashboard and the panel frame to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the angled edge on the lower part of the ProClip into the gap between the control panel and the surrounding frame and slide the ProClip to the left.
3. Press forward on the upper part of the ProClip so the angled edge snaps into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.