

Manual, Assembly instruction: Brodit 852892

Center mount NOT for models with a navigation screen.



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the instrument panel frame and the air vent panel frame to widen the gap.
2. Press the curved edge on the right side of the ProClip into the gap between the air vent panel frame and the climate control panel. Press until you see or hear/feel it snaps into place.
3. Press forward on the left side of the ProClip so the grooved edge goes into the gap between the panel frames below the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.