

Manual, Assembly instruction: Brodit 852894

Center mount



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip

1. Press the thin end of the enclosed gap opener into the gap between air vent house and the air vent frame to widen the gap.

2. Slide/hook the angled edge on the right side of the ProClip into the gap widened by the gap opener. Pull out the gap opener.

3. Press forward on the left side of the ProClip so the angled edge goes into the gap between the padded dashboard and the wood grain panel. Press firmly until you see or hear/feel it snaps into place.

4. The ProClip is in place.