

Manual, Assembly instruction: Brodit 852895

Angled mount



Attention! Read all instructions before attaching the ProClip Part 1: The attaching part (the smallest part)
Part 2: The ProClip faceplate (the big part) Peel off the cover of the adhesive tape on Part 1.

1. Place the thin angled end of Part 1 into the gap between the padded dashboard and the wood grain panel.

2. Press the angled edge firmly into the gap and bend Part 1 to the right until you hear/feel it snaps behind the wood grain panel.

3. Press a screwdriver firmly through the large holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the large holes in Part 2 match the small holes in Part 1 and the adhesive tape on Part 2 is on the left side attaching to the wood grain panel. Screw Part 2 onto Part 1 using the enclosed screws.

4. The ProClip is in place.