

Manual, Assembly instruction: Brodit 852896

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip.

1.Insert/press the angled edge on the lower part on the ProClip into the gap between the wood grain panel and the air vent panel frame.

2. Slide the ProClip to the left, towards the steering wheel, so it is positioned over the left air vent.

3. Press the thin end of the enclosed gap opener into the gap between the instrument panel frame and the padded dashboard to widen the gap. Lift the upper part of the ProClip upwards and forward so the angled edge snaps into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.