

## Manual, Assembly instruction: Brodit 852897

Angled mount

1.)



2.)



3.)



4.)



**Attention! Read all instructions before attaching the ProClip** Part 1: The attaching part (the smallest part)  
Part 2: The ProClip faceplate (the big part) Peel off the cover of the adhesive tape on Part 1 .

**1.** Place the thin angled end of Part 1 into the gap between the padded dashboard and the wood grain panel. Press the angled edge firmly into the gap and bend Part 1 to the right until you hear/feel it snaps behind the wood grain panel.

**2.** Part 1 is in place.

**3.** Press a screwdriver firmly through the large holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the large holes in Part 2 match the small holes in Part 1 and the adhesive tape on Part 2 is on the left side attaching to the wood grain panel. Screw Part 2 onto Part 1 using the enclosed screws. Do not screw the screws straight in but in the angle of Part 1.

**4.** The ProClip is in place.