

Manual, Assembly instruction: Brodit 852899

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the left side of the ProClip into the gap below the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

2. Press down on the top corner of the air vent panel frame with your left hand, to widen the gap between the panel frame and the dashboard. Press the thin end of the enclosed gap opener into the gap.

3. Keep the gap opener in the gap and then press firmly forward on the right side of the ProClip so the angled edge goes into the gap below the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.