

Manual, Assembly instruction: Brodit 852910

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vents and the dashboard to widen the gap. Peel off both adhesive tape covers on the ProClip.

2. Press the lower part of the ProClip into the gap between the frame surrounding the air vents and the control panel.

3. Press forward/upwards on the ProClip so the angled edge of the upper part hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.