

Manual, Assembly instruction: Brodit 852914

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the control panel above the stereo to widen the gap.
2. Press the lower part of the ProClip into the gap next to the gap opener.
3. Hook the grooved edge of the upper part of the ProClip over the edge of the panel by the lower part of the air vent.
4. The ProClip is in place.